



Buddy Green

Teddy finish



Buddy Purple

Teddy finish



Buddy Beige

Teddy finish

Wireless infrared warmer

Targeted contact warmth on both sides, without hot water or filling. The full teddy cover is deliberately soft, thick and shape-retaining.

VERSIONS	Green, Purple and Beige
SIZE	approx. 30 x 20 x 10 cm
POWER	5V USB-A
POWER BANK	RPS-015 - 10,000 mAh
CONTENTS	Buddy, power bank, USB-C charging cable, manual

Before use: check the product, cable, connections and power bank for damage, discoloration and moisture.

Quick start

Use only when clean, dry and undamaged.

1 Charge the power bank

Fully charge the power bank before first use with the included USB-C charging cable and a suitable 5V/2A USB power source.

2 Connect correctly

Insert the Buddy's fixed USB-A plug into one of the two outer USB-A outputs on the power bank.

3 Switch on

Press and hold the button for about 3 seconds. Then press briefly to change the heat setting.

4 Use close to the body

Preheat for 5 to 10 minutes. For clearly noticeable warmth, hold the Buddy directly against your hands, abdomen or lap.

Heat settings and estimated operating time

Guidelines with a fully charged RPS-015; surroundings, contact and battery condition affect the result.

RED

approx. 60 °C

approx. 5.5 hours

BLUE

approx. 50 °C

approx. 7 hours

GREEN

approx. 40 °C

up to 9 hours

Important about the warmth: temperatures refer to the heating element. The thick teddy cover distributes the warmth, so the outside may feel milder. Do not fold or cover tightly to force more heat.

RPS-015 power bank: port overview

Port-side view - the two outer ports are outputs; the two middle ports are charging inputs.



1 USB-A
Output for Buddy

2 USB-C
Charging input
Cable included

3 Micro-USB
Charging input

4 USB-A
Output for Buddy

Charge the power bank

Switch off and disconnect the Buddy. Place the power bank on a dry, heat-resistant surface. Use the included cable in the USB-C input with 5V/2A. Do not charge and heat at the same time.

Use the Buddy

Connect the fixed plug only to an outer USB-A output. A suitable 5V USB power source may also be used. Never use damaged or loose connections.

Troubleshooting

Problem	Check and solution
No warmth	Fully charge the power bank, use a USB-A output, insert the plug firmly and hold the button for about 3 seconds. Then preheat for 5 to 10 minutes.
Button flashes / product switches off	Check the battery charge and plug connection. Fully charge the disconnected power bank. If it switches off repeatedly, stop using it and contact Warmpi.
Power bank does not charge	Use a middle charging input. Check the cable and 5V/2A adapter. Stop immediately if a port is crooked, loose or damaged.
Operating time is much too short	Charge fully and test again on Green. The highest setting, cold conditions and battery ageing reduce operating time. Contact Warmpi if the difference is substantial.
Outside feels lukewarm	Use the Buddy directly against the body and wait 5 to 10 minutes. The thick teddy cover softens the warmth at the surface. Do not fold or cover tightly.
Very hot, smell, stains or swelling	Switch off and disconnect immediately. Do not recharge or use again. Keep away from flammable materials and contact Warmpi.

Safety, care and storage

For Buddy Teddy Green, Purple and Beige with the included RPS-015 power bank



Page 3 of 3



Stop immediately if the product or power bank becomes unusually hot, smells burnt, discolors, swells, becomes wet or is damaged. Disconnect it, do not recharge it and contact Warmpi.

Important safety rules

- Use only for personal warmth and comfort; this is not a medical device.
- Check the Buddy, cable, button, plug and power bank before every use.
- Do not use if moisture, scorch marks, discoloration or damage is visible.
- Do not sharply fold, kink, pierce, crush or use under heavy objects.
- Do not use while sleeping, unattended or in damp surroundings.
- Do not combine with a hot-water bottle, electric blanket or another heat source.
- Children and people with reduced heat sensitivity may use it only under continuous supervision.
- For sensitive skin, begin on Green and check the skin regularly.
- Do not place the power bank on the heating area, cover it tightly or trap it under body weight.
- Charge the power bank only with a suitable 5V USB power source; do not use while charging.
- Do not pull the cable. Keep ports free from dust, liquid and metal objects.
- After use, switch off, disconnect the power source and allow it to cool completely.

Cleaning and storage

- Switch off the Buddy, disconnect the power bank and let everything cool completely.
- Only the fully removed teddy cover may be washed at 30 °C on a delicate cycle. Remove all electrical parts first.
- Never wash or immerse the electrical inner unit, cable, button or power bank.
- Let the cover air-dry completely. Do not bleach, iron or tumble-dry.
- Store dry and flat without heavy objects on top. Lay the cable loosely and avoid sharp bends.

Technical information

Buddy	5V USB-A, approx. 30 x 20 x 10 cm
Heat settings	Green approx. 40 °C / Blue approx. 50 °C / Red approx. 60 °C
Power bank	RPS-015 - 10,000 mAh / 3.7V
Input	5V / 2A
Output	5V / 2.4A
Material	removable teddy cover
Accessory	USB-C charging cable included



Disposal and contact

Do not dispose of electronics or the power bank with household waste. Dispose of both separately according to local regulations. Warmpi - Laning 7, 3202 JC Spijkenisse, The Netherlands - info@warmpi.com - warmpi.com.