

Infrared heated cushion



45 x 45 cm



50 x 30 cm

Direct contact heat from two infrared panels at the front. Operation is the same for standard Warmpi cushions in both sizes.

SIZES	approx. 45 x 45 cm / 50 x 30 cm
HEAT	2 infrared panels - 3 settings
POWER	5V USB - at least 2A
CABLE	integrated - approx. 2.5 m

Before each use, check the cushion, button, cable, USB plug and any power bank for damage, moisture or discolouration.

Quick start

Only use the cushion when it is clean, dry and undamaged.

1 Choose a power source

Use a suitable 5V power bank with an output of at least 2A, or connect the integrated cable to a suitable USB port or 5V/2A USB adapter.

2 Connect

Use the integrated USB-A cable to connect the cushion to your chosen power source. For cordless use, place the power bank and bundled cable together in the pocket on the back of the inner cover.

3 Switch on

Press and hold the Warmpi button on the front of the cushion for about 3 seconds. Then press briefly to change between the three heat settings.

4 Heating up

You will feel warmth within a few minutes. The cushion continues to warm until it reaches its maximum temperature; this may take 5 to 10 minutes, depending on the fabric thickness. Sit against the cushion so it can build up and retain heat.

Heat settings and estimated operating time

Guideline values with a fully charged 10,000 mAh Warmpi power bank; cold, contact and battery condition affect operating time.

RED

ca. 60 °C

up to approx. 3.5 hours

BLUE

ca. 50 °C

up to approx. 5 hours

GREEN

ca. 40 °C

up to approx. 6 hours

Important information about heat: temperatures apply at the heating element. The outer cover spreads and softens the heat. Teddy fabric may therefore take longer to warm fully and may feel slightly less warm than Velvet or Chenille.

Two ways to power the cushion

Depending on the selected version, the cushion is supplied without a power bank or with a power bank.

Without a power bank

Connect the integrated approx. 2.5-metre USB-A cable to a suitable USB port, to the supplied adapter, or to another suitable 5V/2A USB adapter.

With a power bank

10,000 mAh: compact for cordless use; up to approx. 3.5 hours on high, 5 hours on medium and 6 hours on low.

20,000 mAh: approximately twice the capacity and, under the same conditions, approximately twice the operating time.



Connecting the power bank

1. Place the cushion with its back facing up and open the zip of the outer cover. This gives access to the cable and storage pocket on the black inner cover.
2. Connect the cushion's USB-A plug to the power bank. Place the power bank and bundled cable together in the pocket. Close the pocket and then the zip of the outer cover.

Using the long cable

1. Place the cushion with its back facing up and open the zip of the outer cover. This gives access to the cable and storage pocket on the black inner cover.
- Release the hook-and-loop strap around the cable. Connect the cable to the supplied adapter or another suitable 5V/2A USB adapter. Prevent tripping and never pull hard on the cable.

Troubleshooting

Situation	Checks and solution
No heat	Check for 5V/at least 2A, insert USB-A fully, hold the button for about 3 seconds and preheat for 5 to 10 minutes with the heated side facing down.
Button flashes / cushion switches off	Fully charge the power bank, check the connection and test another suitable 5V power supply. Stop using it if it repeatedly switches off.
Outer surface feels lukewarm	Use the front directly against the body. The outer cover reduces the surface temperature. Do not fold double or cover tightly.
Operating time is short	Charge fully and test on Green. The highest setting, a low ambient temperature and an older battery reduce operating time.
USB port or plug becomes hot	Switch off and disconnect immediately. Do not reuse the power supply and contact Warmpi.
Odour, stains, moisture or damage	Switch off and disconnect immediately. Do not use the product again until Warmpi has assessed it.

Charging the power bank: always charge the power bank separately. Do not use the heated cushion while the power bank is charging and monitor the power bank indicator lights.



Stop immediately in the event of unusual heat, a burning smell, discolouration, moisture, damage or a swollen power bank. Disconnect the power supply and contact Warmpi.

Important safety rules

- For personal warmth and comfort only; this is not a medical device.
- Check the cushion, button, cable, plug and power bank before each use.
- Do not use if the product is wet, damp, damaged or discoloured.
- Do not fold sharply, kink, pierce, crush or use under heavy objects.
- Do not use while sleeping, unattended or in a damp environment.
- Do not combine with a hot-water bottle, electric blanket or other heat source.
- Children and people with reduced heat sensitivity require constant supervision.
- For sensitive skin, start on Green and check the skin regularly.
- Do not place the power bank on a heating panel or trap it under body weight.
- Only use a suitable 5V power supply with at least 2A; do not use the cushion while the power bank is charging.
- Keep connectors free of dust, liquids and metal objects.
- After use, switch off, disconnect the power and let the cushion cool.

Cleaning

- Switch off, disconnect the power and let the cushion cool completely.
- Open the outer cover and remove the power bank and cushion filling from the black inner cover.
- Fit the rubber protective cap on the cable firmly over the USB-A connector. Close the outer cover with the zip and wash the cushion at no more than 30 °C on a delicate cycle.
- Allow the cover to air-dry completely. Do not bleach, iron or tumble-dry.

This manual applies to

Size	Versions	Shared technology
45 x 45 cm	Teddy, Chenille, Velvet and Limited Edition	2 infrared panels at the front, 3 settings, 5V USB, min. 2A
50 x 30 cm	Teddy, Chenille and Velvet	2 infrared panels at the front, 3 settings, 5V USB, min. 2A

Technical information

Product	Warmpi heated cushion - approx. 45 x 45 cm or 50 x 30 cm
Heat	2 infrared panels - Green approx. 40 °C / Blue approx. 50 °C / Red approx. 60 °C
Power	5V USB - at least 2A
Cable	integrated - approx. 2.5 m
Power bank	optional 10,000 or 20,000 mAh
Use	direct contact heat, indoor use

Disposal and contact

Dispose of electronics and power banks separately in accordance with local regulations.

Warmpi - Laning 7, 3202 JC Spijkenisse, the Netherlands - info@warmpi.com - warmpi.com.